



ATTACHING GEN 2 MOLLE SAR CASE TO PACKS

To attach MOLLE SAR case to GEN 1 SCS packs:

1. Remove the SCS fire shelter case from the bottom of the pack by unbuttoning the tri-glides on the bottom of the pack from the D-rings on the SCS fire shelter case.
2. Unthread the MOLLE tabs from the 1" tri-glides and 2 rows of MOLLE web on SAR case.
3. Thread the 1" MOLLE tabs on the SAR case through the tri-glides on the bottom of the pack closest to the waist belt.
4. Thread the 1" MOLLE tabs through the MOLLE web on the SAR case.
5. Thread the 1" MOLLE tabs through the 1" tri-glides on the bottom of the pack next to the pocket and pull tight.
6. Tuck excess web under the SAR case MOLLE loops.





To attach MOLLE SAR case to a GEN 2 Pack:

1. Remove the fire shelter case from the bottom of the pack by undoing the MOLLE web that holds the fire shelter case to the bottom of the pack. Set the fire shelter case aside.
2. Remove the 1" compression straps with the side release buckles on the SAR case from their loops and set them aside. These were meant for an earlier design and are no longer needed.
3. To make attachment easier undo the three buckles that are connected to the front pocket. Then undo the zipper at the bottom of the gear bag to allow the entire pack to lay flat. Turn the pack over so the waist belt and the reflective material on the front pocket are face-up.
4. Remove the Adapter Straps included with these instructions from the bag. Locate the widest set of MOLLE loops nearest the outer edge on the bottom of the pack. Starting with the row of MOLLE web on the pack closest to the front pocket (Row C), thread the cut end of the Adapter Straps under all three rows of MOLLE web on the bottom of the pack and pull the web tight so that the tri-glide buckle is snug against the MOLLE web.
5. Lay the SAR case down on the waist belt with the MOLLE loops facing upward making sure the True North logo on the SAR case is facing the MOLLE loops on the pack. Begin by locating the MOLLE loops on the SAR case which are to the inside (closer to the center) of the straps already on the bottom of the SAR case (this is the white line with the 'x' shown in the picture). There are three rows of MOLLE loops (labeled 1,2,3 in the picture). Thread the cut end of the 1" Adapter Straps through the loop in Row 1. Thread the Adapter Straps through ONLY Row 1 of the MOLLE straps on the SAR case.
6. There are three lines of MOLLE webbing on the bottom of the pack. Continue by weaving the 1" Adapter Straps back under the center row (Row B) of the three rows of webbing on the bottom of the pack. Use the same row of MOLLE loops that the Adapter Strap is under.
7. Next weave the Adapter Strap back under the center row of webbing (Row 2) on the bottom of the SAR case.
8. Next weave the Adapter Strap under the last row of webbing (Row C) under the pack, and then back under the last row of webbing (Row 3) on the SAR case.
9. Next, thread the cut end of the Adapter Strap through the 1" tri-glides on the Adapter Strap and pull tight until SAR case is as snug as possible. Tuck loose web under bottom of pack.

